



24v - USB - Cable - Programming - Guide

Parts in the Box #201348



Programming Dongle




USB to SDN cable

1. Install Somfy Motor Configuration Software on a Windows PC.



Scan the QR code to download the software or, use this url below to download it under the guides on this page, <https://support.screeninnovations.com/accessories/usb-programming-kit/#dd8bc475ccd3e5ba0>

2. Connect the USB programming cable to the RJ45 connector on the included Programming Dongle, and then connect your Shade Terminal from your screen to the white terminal block header on the same dongle, and finally connect the Shade Power supply (or pre wire from your Power panel to the green terminal connection on the dongle).
3. Open the Somfy SDN Motor Configuration Software, and select the USB cable com port from the upper left box, and now click on get single motor address and you are ready to set your limits. The complete manual for programming with this cable is also on the USB drive.



This Kit was designed to program one Motor or one Keypad at a time.
Screen Innovations does not support usage of this kit in any way other than described above.